



## Wiring diagram

There are strict sequence requirements for the power-on of the protection plate. First weld B-,P-,B+,P+,and sequentially plug in the battery sampling line connector from low to high. After power-on, press the key to activate it. Load or charger can only be added after all connecting wires are installed. When removing, unplug the charger or load First, remove the battery sampling line connector in sequence from high to low,and finally remove B+,P+,B-,P-

